



Remove axles with the 1.5 Halen key included. Pay attention to use the correct Halen key. Loose or tight any screws carefully.

Don't remove the hinge, except for annual cleaning.

The head can be removed for cleaning, and to change the moon cam.



Loose the side screw with the 2 Halen key to free the moon cam.



To set the travel adjustment, use the 2 Halen key into the stem to find the screw.



Tight clockwise to make it longer.

Loose anticlockwise
to make it softer

Made in France

Arc système ZA La Novialle - 8 rue du Montel 63670 La roche blanche - FRANCE Tél: (33) 04 73 37 93 95 Fax: (33) 04 73 37 03 74 Email: contact@arc-systeme.fr









http://www.arc-systeme.fr